

Countertop Installation



For installing a custom countertop to a frame assembly.

Parts Include:
 4 - 2" L Brackets
 12 - Self Tapping 3/4" Screws

Drill is required for attaching top.



1

Start with your assembled frame(s).



2

Slide your 3 sided or 4 sided countertop onto the open frame.



3

On a single sided countertop, line the sides up with your frame.



4

Position L bracket under the top near one of the corners. Drive 1st screw in place.



5

Drive 2nd screw in place. NOTE: the position of the bracket does not need to be perfect.



6

Drive the 3rd screw in place.



7

Installation is complete!

Install all 4 brackets near the corners of the counter top as shown.

Note: The flat pan head on the screw will prevent any chance of screwing too far into the wood top.



Screw cannot go all the way through the top.